

SUPPLEMENTARY MANUAL

for iQSE-1 + QSH-F1E

SECURE THE BIKE ON A STAND.



LOCATE THE FUEL INJECTOR CONNECTOR UNDER THE FUEL TANK.



CONNECT THE QSH CONNECTORS IN-LINE WITH THE INJECTOR CONNECTORS.





SUPPLEMENTARY MANUAL

for iQSE-1 + QSH-F1E

CONNECT THE QSH BLACK WIRE TERMINAL TO THE BATTERY NEGATIVE TERMINAL.



USE THE ORIGINAL BOLT OF THE GEARBOX SHAFT, ADD THE SENSOR AND THE ORIGINAL WASHER EXACTLY AS SHOWN IN THIS PHOTO.



MOUNT THE QSE SENSOR.

(TIGHTEN THE BOLT IN THIS POSITION BY ABOUT 6 NM. IF YOU DO NOT HAVE A TORQUE WRENCH, TIGHTEN THE BOLT UNTIL THE SHIFT ARM IS TIGHT ON THE GEARBOX SHAFT.)





SUPPLEMENTARY MANUAL

for iQSE-1 + QSH-F1E

Typical position for the QuickShifter easy.

SECURE THE UNIT PROPERLY.

