

Benelli TRK 502

2017-



SUPPLEMENTARY MANUAL

for iQSE-1 + QSX-F2C

REMOVE THE SEATS.



REMOVE THE SIDE BLACK PLASTIC
COVERS.



PLUG THE QSX CONNECTORS
IN-LINE WITH THE FUEL INJECTOR
CONNECTORS.
(BLACK, 2-POLE CONNECTORS BELOW THE FUEL TANK.)



Benelli TRK 502

2017-



SUPPLEMENTARY MANUAL

for iQSE-1 + QSX-F2C

CONNECT THE QSH BLACK WIRE
TERMINAL TO THE BATTERY
NEGATIVE TERMINAL.

MOUNT THE QSE SENSOR UNDER
THE BOLT OF GEARBOX SHAFT.

(TIGHTEN THE BOLT BY ABOUT 5-6 NM.
IF YOU DO NOT HAVE A TORQUE WRENCH,
TIGHTEN THE BOLT UNTIL THE SHIFT ARM
IS TIGHT ON THE GEARBOX SHAFT.)



TYPICAL POSITION FOR THE
QUICKSHIFTER EASY.

SECURE THE MODULE PROPERLY.

