



# SUPPLEMENTARY MANUAL

for iQSE-1 + QSH-P4B

REPLACE THE BOLT WITH THE ONE  
SUPPLIED.

PLACE THE CONICAL WASHERS AT  
THE TWO SIDES OF THE SENSOR  
LIKE THIS: (O).

PLEASE ADD MORE FLAT WASHERS  
TO BRIDGE THE GAP AND BRING THE  
SENSOR BODY FAR ENOUGH OUT SO  
IT WILL NOT RUB ON THE SHIFT  
LEVER.

THIS WAY THE PROPER FORCE CAN BUILD UP TO  
TRIGGER THE CUT WITHOUT DAMAGING THE SENSOR.



TIGHTEN THE BOLT IN THIS  
POSITION BY ABOUT 6 NM.

