



## SUPPLEMENTARY MANUAL

for QSE-1 + QSH-P2A

REMOVE THE MAIN SEAT.



REMOVE THE  
FUEL TANK COVERS.



PLUG THE QSH CONNECTOR PAIR  
WHICH IS MARKED WITH RED  
SQUARE IN-LINE WITH THE IGNITION  
COIL CONNECTOR.  
(BLACK, 2-POLE CONNECTOR BELOW FUEL TANK)



# Yamaha WR250X

2008-2015



**CONNECT QSH BLACK WIRE  
TERMINAL TO CHASSIS GROUND.**



**MOUNT THE QSE SENSOR.**  
(USE A NEW M6 BOLT WITH NUT INSTEAD OF THE  
ORIGINAL M8 BOLT. MAKE SURE TO PLACE ONE  
WASHER ABOVE THE SENSOR AND ONE WASHER  
BELOW THE SENSOR.  
TIGHTEN THE SCREW BY 3-4 NM.

WHEN TIGHTENED, DO NOT TRY TO ROTATE THE  
SENSOR BODY)



**TYPICAL POSITION FOR THE  
QUICKSHIFTER EASY.**

