# KTM 1290 Super Duke R / GT



#### SUPPLEMENTARY MANUAL

for iQSE-1 + QSR-F2F

REMOVE THE SEATS.



REMOVE THE LEFT AND RIGHT SIDE COVERS WITH  $\label{eq:theorem} \text{THE BLINKERS.}$ 



REMOVE THE LOWER PLASTIC COVERS AROUND THE FUEL TANK.



## KTM 1290 Super Duke R / GT



### SUPPLEMENTARY MANUAL

for iQSE-1 + QSR-F2F

REMOVE THE FUEL TANK.



REMOVE THE AIRBOX.



CONNECT THE QSH CONNECTORS IN-LINE WITH THE INJECTOR CONNECTORS.



### KTM 1290 Super Duke R / GT



#### SUPPLEMENTARY MANUAL

for iQSE-1 + QSR-F2F

CONNECT THE QSH BLACK WIRE TERMINAL TO THE CHASSIS GROUND.



REMOVE THE OEM SHIFT ROD.

INSTALL THE SUPPLIED M6 SHIFT ROD.

#### MOUNT THE QSE SENSOR.

(INSTALL THE SENSOR IN THE ROD WITHOUT THE CONICAL WASHERS, SO THE SENSOR ONLY.
TIGHTEN THE NUT FULLY BY HAND THEN BY ABOUT 30
DEGREES USING A WRENCH.)



Typical position for the QuickShifter easy.

SECURE THE UNIT PROPERLY.

