

GI-pro X TYPE
GPX_U01 harness (universal)
Installation Instructions on MOTO GUZZI NORGE 1200 ABS 2012 :

Installation :

- 1) Using the supplied wire tap connect the GiPro RED wire to a positive +12v switched.
- 2) Connect the GiPro BLACK wire to the negative side of the battery, or to a good ground position.
- 3) Locate the black 3 pin Cranck Pick-up connector.
This connectors is located below the fuel tank and between the two cylinders.
This connector has Brown, White and Black wires.
- 4) Using the supplied wire tap connect the GiPro GREEN wire to the stock WHITE wire that is in the central position.
- 5) Locate the WHITE/GRAY wire (speed wire) that connect the ABS ECO to the Engine ECU.
- 6) Using the supplied wire tap connect the GiPro WHITE wire to the stock WHITE/GRAY.

Nota:

The speed signal from ABS ECU to Engine ECU is based on the rotation of the front wheel, so to perform the speed test you need to rotate the front wheel.

For the same reason, to program the GiPro X-type you need to ride the bike on the road.