

SUPPLEMENTARY MANUAL

for SH-UO1

REMOVE THE SEAT.



UNPLUG THE ECU CONNECTOR.

(BLACK, CONNECTOR UNDER THE FUSE BOX)



SPLICE THE SPEEDOHEALER RED WIRE TO ORANGE WIRE OF REAR BRAKELIGHT SWITCH CONNECTOR.

(transparent, 2-pole connector at right side near battery)





SPLICE THE SPEEDOHEALER BLACK WIRE TO THE BLACK/WHITE WIRE.

(PIN NUMBER 25)

CUT THE PINK/WHITE WIRE ABOUT 4CM (1.5") AWAY FROM THE CONNECTOR.

(PIN NUMBER 3)



SPLICE THE
SPEEDOHEALER WHITE WIRE TO
THE PINK/WHITE WIRE END,
WHICH GOES TO THE
ECU CONNECTOR.

SPLICE THE SPEEDOHEALER GREEN WIRE TO THE PINK/WHITE WIRE END, WHICH IS AT THE WIRING HARNESS SIDE.



RECOMMENDED POSITION FOR SPEEDOHEALER.







TYPICAL POSITION FOR TSM SWITCH.

