



SUPPLEMENTARY MANUAL

for QSH-P4A

REMOVE THE SEATS.

**REMOVE OR LIFT UP THE FUEL
TANK.**

**REMOVE THE RADIATOR COVER SIDE
PANELS.**



**CONNECT THE QSH CONNECTORS
IN-LINE WITH THE IGNITION COIL
CONNECTORS.**



**CONNECT THE QSH BLACK WIRE
TERMINAL TO THE CHASSIS
GROUND**





SUPPLEMENTARY MANUAL

for QSH-P4A

MOUNT THE QSE SENSOR.

(REPLACE THE BOLT WITH THE ONE SUPPLIED.
TIGHTEN THE BOLT IN THIS POSITION BY
ABOUT 5-6 NM.

IF YOU DO NOT HAVE A TORQUE WRENCH,
TIGHTEN THE BOLT UNTIL THE
SHIFT ARM IS TIGHT ON THE GEARBOX SHAFT.

FOR DIFFERENT MOUNTING OPTIONS,
REFER TO THE SENSOR INSTALL GUIDE.)



TYPICAL POSITION FOR THE
QUICKSHIFTER EASY.

SECURE THE UNIT PROPERLY.

IF YOU WISH TO SEE AN INSTALL
VIDEO, PLEASE [CLICK HERE](#).

