

Ducati Monster 1200

2014-



SUPPLEMENTARY MANUAL

for iQSE-1 + QSH-F1A

REMOVE THE SEAT.



REMOVE THE
IGNITION SWITCH COVER.



LIFT UP OR REMOVE
THE FUEL TANK.





SUPPLEMENTARY MANUAL

for iQSE-1 + QSH-F1A

**PLUG THE QSH CONNECTOR IN-
LINE WITH THE FUEL INJECTOR
CONNECTOR.**
(WHITE, 3-POLE CONNECTOR ON AIRBOX)



**CONNECT THE QSH BLACK WIRE
TERMINAL TO THE CHASSIS
GROUND.**



MOUNT THE QSE SENSOR.

(REPLACE THE BOLT WITH THE ONE SUPPLIED.
PLACE THE CONICAL WASHERS AT THE TWO SIDES OF
THE SENSOR LIKE THIS: (O). TIGHTEN THE BOLT IN
THIS POSITION BY ABOUT 5 NM. IF YOU DO NOT HAVE
A TORQUE WRENCH, TIGHTEN THE BOLT UNTIL THE
SHIFT ARM IS TIGHT ON THE GEARBOX SHAFT.
FOR DIFFERENT MOUNTING OPTIONS,
REFER TO THE SENSOR INSTALL GUIDE.)



Ducati Monster 1200

2014-



SUPPLEMENTARY MANUAL

for IQSE-1 + QSH-F1A

TYPICAL POSITION FOR THE
QUICKSHIFTER EASY.

