

Triumph Tiger Sport 2013-



SUPPLEMENTARY MANUAL

for iQSE-1 + QSH-P4B

REMOVE THE SEAT.



REMOVE THE FUEL TANK COVERS
AND THE SIDE FAIRINGS.



REMOVE THE FUEL TANK AND THE
AIRBOX.





SUPPLEMENTARY MANUAL

for iQSE-1 + QSH-P4B

CONNECT THE QSH CONNECTORS
IN-LINE WITH THE IGNITION COIL
CONNECTORS.



CONNECT THE QSH BLACK WIRE
TERMINAL TO THE MAIN CHASSIS
GROUND.



MOUNT THE QSE SENSOR.
(REPLACE THE BOLT WITH THE ONE SUPPLIED.
TIGHTEN THE BOLT IN THIS POSITION BY
ABOUT 5-6 NM.
IF YOU DO NOT HAVE A TORQUE WRENCH,
TIGHTEN THE BOLT UNTIL THE
SHIFT ARM IS TIGHT ON THE GEARBOX SHAFT.

(FOR DIFFERENT MOUNTING OPTIONS,
REFER TO THE SENSOR INSTALL GUIDE.)





SUPPLEMENTARY MANUAL

for iQSE-1 + QSH-P4B

TYPICAL POSITION FOR THE
QUICKSHIFTER EASY.

SECURE THE UNIT PROPERLY.

