

SUPPLEMENTARY MANUAL

for GPDS-HO1

REMOVE THE SEAT.



REMOVE THE LEFT AND RIGHT FRAME COVER BELOW THE SEAT.

LIFT UP OR REMOVE THE FUEL TANK.



CONNECT DS-SERIES CONNECTOR
TO

DIAGNOSTIC SYSTEM CONNECTOR.

(RED, 4-POLE CONNECTOR WITH RED CAP UNDER SEAT NEAR BATTERY)





TYPICAL POSITION FOR THE GEAR INDICATOR.

