

## SUPPLEMENTARY MANUAL

for GPDS-KO1

REMOVE THE SEAT.



REMOVE THE BLACK FRAME COVERS FROM FUEL TANK.

LIFT UP OR REMOVE THE FUEL TANK.



CONNECT DS-SERIES CONNECTOR

DIAGNOSTIC SYSTEM CONNECTOR.

(BLACK, 4-POLE KDS CONNECTOR WITH DUMMY PLUG (WITHOUT WIRES) AT THE RIGHT SIDE OF THE FRAME)







TYPICAL POSITION FOR THE GEAR INDICATOR.

