



SUPPLEMENTARY MANUAL

for GPDS-K01

REMOVE THE MAIN AND PASSENGER SEATS.
LIFT UP OR REMOVE THE FUEL TANK.



CONNECT DS-SERIES CONNECTOR TO
DIAGNOSTIC SYSTEM CONNECTOR.
(BLACK, 4-POLE KDS CONNECTOR WITH
DUMMY PLUG (WITH ONE YELLOW WIRE)
AT THE RIGHT SIDE UNDER SEAT NEAR FRAME)



TYPICAL POSITION FOR THE
GEAR INDICATOR.

