

SUPPLEMENTARY MANUAL

for GPDS-KO2

REMOVE THE MAIN AND PASSENGER SEATS.
REMOVE THE FRAME COVERS
UNDER THE FUEL TANK.
LIFT UP OR REMOVE THE
FUEL TANK.



CONNECT DS-SERIES CONNECTOR
TO

DIAGNOSTIC SYSTEM CONNECTOR.

(GRAY, 4-POLE KDS CONNECTOR WITH DUMMY PLUG AT THE RIGHT SIDE UNDER THE SEAT)



TYPICAL POSITION FOR THE GEAR INDICATOR.

