

SUPPLEMENTARY MANUAL

for GPDS-KO4

REMOVE THE PASSENGER
AND MAIN SEATS.
LIFT UP OR REMOVE THE
FUEL TANK.



CONNECT DS-SERIES CONNECTOR

DIAGNOSTIC SYSTEM CONNECTOR.

(TRANSPARENT, 4-POLE KDS CONNECTOR WITH WHITE CAP UNDER MAIN SEAT)



TYPICAL POSITION FOR THE GEAR INDICATOR.

