## Triumph Speed Triple 1050



## SUPPLEMENTARY MANUAL

for GPDS-T01

REMOVE THE SEAT.



REMOVE THE BLACK COVERS FROM FRONT OF FUEL TANK.

LIFT UP OR REMOVE THE FUEL TANK.



CONNECT DS-SERIES CONNECTOR

TO
DIAGNOSTIC SYSTEM CONNECTOR.

(BLACK, 16-POLE CONNECTOR UNDER SEAT)



## Triumph Speed Triple 1050



CONNECT DS-SERIES RED WIRE

ORANGE/GREEN WIRE OF RELAY UNIT.

(BLACK RELAY UNIT, NEXT TO THE FUSE BOX UNDER SEAT)



TYPICAL POSITION FOR THE GEAR INDICATOR.

