

Suzuki GSF600 Bandit 2000-2004



SUPPLEMENTARY MANUAL for GPX-S01


REMOVE THE MAIN SEAT.
REMOVE THE FRAME COVER
UNDER SEAT AT LEFT SIDE.



REMOVE THE KNOB OF FUEL TAP.
LIFT UP OR REMOVE THE
FUEL TANK.



PLUG GPX CONNECTORS IN-LINE
WITH THE SPEED SENSOR
CONNECTORS.
(BLACK, 3-POLE CONNECTORS AT LEFT SIDE
NEAR MAIN RELAY)




Suzuki GSF600 Bandit

2000-2004



**CONNECT GPX BLACK/GREEN WIRE
TO
BLACK/BLUE WIRE OF ECU/ECM
UNIT.**

(BLACK, 8-POLE CONNECTOR
AT LEFT SIDE BELOW THE REAR FAIRING)



**TYPICAL POSITION FOR THE
GEAR INDICATOR.**

