

Kawasaki ZX-10R

2006-2007




SUPPLEMENTARY MANUAL

for SH-K06

REMOVE THE
FRAME COVERS BELOW MAIN SEAT.



REMOVE THE MAIN SEAT.



LIFT UP OR REMOVE THE
FUEL TANK.




Kawasaki ZX-10R

2006-2007



**PLUG SPEEDOHEALER CONNECTORS
IN-LINE WITH THE VEHICLE SPEED
SENSOR (VSS) CONNECTORS.**

(BLACK, 3-POLE CONNECTORS
AT LEFT SIDE BEHIND WATER HOSE)



**TYPICAL POSITION
FOR SPEEDOHEALER.**

