

SUPPLEMENTARY MANUAL

for SH-SO1

REMOVE THE MAIN SEAT.



LIFT UP OR REMOVE THE FUEL TANK.



PLUG SPEEDOHEALER CONNECTORS
IN-LINE WITH THE VEHICLE SPEED
SENSOR (VSS) CONNECTORS.

(BLACK, 3-POLE CONNECTORS AT LEFT SIDE BELOW FUEL TANK)







TYPICAL POSITION FOR SPEEDOHEALER.

