

SUPPLEMENTARY MANUAL

for iQSE-1 + QSH-P4A

REMOVE THE SEATS.



REMOVE THE SIDE FAIRINGS.



REMOVE THE FUEL TANK.





SUPPLEMENTARY MANUAL

for iQSE-1 + QSH-P4A

PLUG ALL THE QSH CONNECTORS
IN-LINE WITH THE IGNITION COIL
CONNECTORS.

(BLACK, Z-POLE CONNECTORS BELOW THE FUEL TANK.)



CONNECT THE QSH BLACK WIRE TERMINAL TO THE CHASSIS GROUND.



Mount the \mathbf{QSE} sensor.

(REPLACE THE BOLT WITH THE ONE SUPPLIED.
TIGHTEN THE BOLT IN THIS POSITION BY
ABOUT 5-6 NM.
IF YOU DO NOT HAVE A TORQUE WRENCH,
TIGHTEN THE BOLT UNTIL THE
SHIFT ARM IS TIGHT ON THE GEARBOX SHAFT.
FOR DIFFERENT MOUNTING OPTIONS,
REFER TO THE SENSOR INSTALL GUIDE.)







SUPPLEMENTARY MANUAL

for iQSE-1 + QSH-P4A

TYPICAL POSITION FOR THE QUICKSHIFTER EASY.

SECURE THE MODULE PROPERLY.

