

SUPPLEMENTARY MANUAL

for BLP-UO1

REMOVE THE MAIN SEAT.




LOCATE THE REAR LIGHT CONNECTOR UNDER MAIN SEAT.


(TRANSPARENT, 6-POLE CONNECTOR)



CUT THE WHITE/BLACK WIRE.
CONNECT THE BLP RED WIRE TO
WHITE/BLACK WIRE END, WHICH
GOES TO THE REAR LIGHT
CONNECTOR.



CONNECT THE BLP GREEN WIRE TO WHITE/BLACK WIRE END, WHICH IS AT THE WIRING HARNESS SIDE.



CONNECT THE BLP BLACK WIRE TO BLACK/WHITE WIRE OF REAR LIGHT CONNECTOR.



TYPICAL POSITION FOR BRAKE LIGHT PRO.

