

Kawasaki Z750R


2011-2012




SUPPLEMENTARY MANUAL

for ESE-KO1

REMOVE THE
PASSENGER AND MAIN SEAT.



REMOVE THE
LEFT SIDE FRAME COVERS.



UNPLUG THE
EXHAUST SERVO-MOTOR
CONNECTORS.
(WHITE, 3-POLE TRIANGULAR AND TRANSPARENT, 2-
POLE CONNECTORS BELOW LEFT SIDE FRAME COVER)



Kawasaki Z750R


2011-2012



REMOVE THE
EXHAUST SERVO-MOTOR.



PLUG ESE CONNECTORS TO
EXHAUST SERVO-MOTOR
CONNECTORS.



TYPICAL POSITION
FOR EXHAUST SERVO ELIMINATOR.

