




SUPPLEMENTARY MANUAL

for GPX-U01


REMOVE THE FAIRINGS FROM
RIGHT SIDE.
REMOVE THE RELAY HOLDER.



CONNECT GPX WHITE WIRE TO
BLUE WIRE OF ECU/ECM
CONNECTOR.
(BIG CONNECTOR OF ECU/ECM, PIN #32,
BEHIND RELAY HOLDER)



CONNECT GPX GREEN WIRE TO
GRAY WIRE OF
CRANKSHAFT POSITION SENSOR
CONNECTOR.
(BLACK, 2-POLE CONNECTOR
AT RIGHT SIDE)



Yamaha XT1200Z

2010-2013



**CONNECT GPX RED WIRE TO
BROWN WIRE AT THE WIRE
DISTRIBUTOR CONNECTOR.**

(BLACK CONNECTOR AT RIGHT SIDE
NEAR MAIN RELAY)

**CONNECT GPX BLACK WIRE TO
NEGATIVE SIDE OF BATTERY.**

