

SUPPLEMENTARY MANUAL

for GPX-YO1

REMOVE THE MAIN SEAT. LIFT UP OR REMOVE THE FUEL TANK.



PLUG GPX CONNECTORS IN-LINE
WITH THE SPEED SENSOR
CONNECTORS.

(WHITE, 3-POLE TRIANGULAR CONNECTORS AT RIGHT SIDE BELOW FUEL TANK)



CONNECT GPX BLACK/GREEN WIRE

TO

GRAY WIRE OF ECU CONNECTOR.


(BLACK CONNECTOR, PIN #8)





CONNECT GPX RED WIRE TO BROWN WIRE OF REAR BRAKELIGHT SWITCH CONNECTOR.

(TRANSPARENT, Z-POLE CONNECTOR AT RIGHT SIDE BELOW FUEL TANK)



TYPICAL POSITION FOR THE GEAR INDICATOR.

