

SUPPLEMENTARY MANUAL

for GPDS-D01

REMOVE THE MAIN AND PASSENGER SEATS.

LIFT UP OR REMOVE THE FUEL TANK.



CONNECT DS-SERIES CONNECTOR

DIAGNOSTIC SYSTEM CONNECTOR.

(BLACK, 4-POLE CONNECTOR WITH BLACK CAP BELOW PASSENGER SEAT



TYPICAL POSITION FOR THE GEAR INDICATOR.

