

SUPPLEMENTARY MANUAL

for GPX-HO2

REMOVE THE SEATS.



REMOVE THE BLACK FRAME COVERS

AT BOTH SIDE FROM UNDER

FUEL TANK.

LIFT UP OR REMOVE THE

FUEL TANK.

ROUTE THE GPX CABLE THROUGH


THE TOP OPENING OF THE

DUST BOOT.



PLUG GPX CONNECTORS IN-LINE
WITH THE SPEED SENSOR
CONNECTORS.

(BLACK, 3-POLE CONNECTORS IN DUST BOOT AT THE LEFT SIDE)





CONNECT GPX BLACK/GREEN WIRE TO

YELLOW WIRE OF CRANKSHAFT POSITION SENSOR CONNECTOR.

(BLUE, Z-POLE CONNECTOR IN DUST BOOT AT LEFT SIDE)



TYPICAL POSITION FOR THE GEAR INDICATOR.

