

Honda CRF1000L Africa Twin (DCT) 2016-

SUPPLEMENTARY MANUAL for SH-U01

Here is how to make it work without affecting the shifts.

Connect the SH wires either at the 32-pole dashboard connector or at the 12-pole Gray connector a bit farther from the dash, see the image on the second page.

- 1) Cut the **Pink** wire.
- 2) Connect the **SH White** to the Pink wire end at the wiring harness side.
- 3) Connect the **SH Green** to the Pink wire end at the speedometer side.
- 4) Connect the **SH Black** wire to the **Green** wire.
- 5) Connect the **SH Red** wire the **Black/Red** wire.

When the installation is done, do the SH signal test procedure as follows:

- Have the ignition key OFF.
- Press SEL and keep it depressed while you turn the ignition ON.
[t] (test) is now indicated. Release the button.
Check: The speedometer should indicate a steady number other than 0.
- Move the bike back and forth so both wheels are turning.
Check: [t] should be blinking as the wheels turn.

Note: [t] appears on the display like an [E] without the top horizontal bar.

