



# **SUPPLEMENTARY MANUAL**

for XT-S01

**REMOVE THE MAIN SEAT.  
REMOVE BLACK FRAME COVERS  
FROM LEFT AND RIGHT SIDE  
BELOW SEAT.**



**REMOVE THE BLACK COVER  
FROM IGNITION SWITCH.  
REMOVE FAIRINGS WITH INDICATOR  
FROM LEFT AND RIGHT SIDE.**



**LIFT UP OR REMOVE THE  
FUEL TANK.**



# Suzuki GSR600

2006-2011



**PLUG X-TRE CONNECTORS IN-LINE WITH THE GEAR POSITION SENSOR CONNECTORS.**

(WHITE, 3-POLE TRIANGULAR CONNECTORS BELOW THE FUEL TANK AT LEFT SIDE)

**MOUNT THE X-TRE BOX TO THE INNER SIDE OF THE FRAME BY THE SUPPLIED VELCRO STRIPS, AND SECURE THE BOX AND CABLES WITH CABLE TIES.**



**CUT THE BLACK/GREEN WIRE ABOUT 4CM (1.6") AWAY FROM THE ECM CONNECTOR.**

(LARGE CONNECTOR, PIN #6)

**CONNECT THE X-TRE BLACK/GREEN WIRE TO BLACK/GREEN WIRE END, WHICH GOES TO THE ECM CONNECTOR.**

**CONNECT THE X-TRE BLACK/WHITE WIRE TO BLACK/GREEN WIRE END, WHICH IS AT THE WIRING HARNESS SIDE.**



**CONNECT X-TRE RED WIRE TO ORANGE WIRE OF REAR BRAKE LIGHT SWITCH CONNECTOR.**

(TRANSPARENT, 2-POLE CONNECTOR BELOW FUEL TANK)

(X-TRE MODE: 6)

