



SUPPLEMENTARY MANUAL

for BLP-UO1

REMOVE THE MAIN AND PASSANGER SEAT.



LOCATE THE REAR LIGHT CONNECTOR BETWEEN PASSANGER AND MAIN SEAT. (WHITE, 3-POLE TRIANGULAR CONNECTOR)






CUT THE YELLOW WIRE. CONNECT THE BLP RED WIRE TO YELLOW WIRE END, WHICH IS AT THE WIRING HARNESS SIDE.









CONNECT THE BLP BLACK WIRE TO BLACK WIRE.





TYPICAL POSITION FOR BRAKE LIGHT PRO.